


PROCARPET ALL

NATURAL AND ANODIZED SILVER ALUMINIUM



NATURAL ALUMINIUM thermo packed 5 Pcs

and intense pedestrian traffic.

Dar length 2,70 m - pack. 20 PCS - 54 m			
Article	H mm		
PRTAN 08	8		
PRTAN 10	10		
PRTAN 125	12,5		

INSTRUCTIONS FOR LAYING 1. Choose the "PROCARPET ALL" taking into consideration the exact 1. Choose the "PROCARPELALL" taking into consideration the exact height of the floor. 2. Using a notched spreader apply the adhesive onto the area of application of the profile. 3. Lay and align the profile, cut to the necessary length, pressing the perforated flange into the adhesive. 4. Lay the tiles, aligning them so that the top edge of the profile is "flush" with the tile. 5. Fill the profile/tile area of contact with adhesive to prevent the accumulation of water in anyunide. any voids.



ANODIZED SILVER ALUMINIUM thermo packed bar length 2,70 lm - pack. 20 Pcs - 54 lm

AN - Natural alum

PROSKID is a brass and aluminum profile that allows to connect continuously and without steps two adjacent floors that are located on two different levels and protect the edges of the floor. PROSKID in brass and silver anodized aluminium is suitable for any environment where good resistance to mechanical and chemical stress is required.

PROCARPET ALL is a profile in aluminium (natural or silver anodized) used for joining two floors of differing

thickness and in particular for joining a tiled or parquet floor to wall-to-wall carpeting, making a perfect join thanks to the vertical part of less than 4 mm. In addition to completely protecting the edge of the higher floor, this particularly sturdy profile withstands high loads and supports the frequent passage of manual trolleys, vehicles


Article	Hmm	
PRTAA 08	8	
PRTAA 10	10	
PRTAA 125	12,5	

AA - Anodized silver alum


PROSKID

POLISHED BRASS AND ANODIZED SILVER ALUMINIUM

PSLDOL 10/109/109AS transition profiles



EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS



1. Choose the "PROCARPET" taking into consideration the exact height of the floor. 2. Using a notched spreader apply the adhesive onto the area of application of the profile. 3. Lay and align the profile, cut to the necessary length, pressing the perforated flange into the adhesive. 4. Lay the tiles, aligning them so that the top edge of the profile is "flush" with the tile. 5. Fill the profile/lie area of contact with adhesive to prevent the accumulation of water in any voids.



POLISHED BRASS thermo packed			
bar length 2,70 lm - pack. 20 Pcs - 54 lm			
Article	H mm		
PSLDOL 10	10		

POLISHED BRASS thermo packed bar length 0,90 lm - pack. 20 Pcs		F	SELF PACK
Article	Hmm		
PSLDOL 109AS	10		



ANODIZED SILVER ALUMINIUM thermo packed bar length 2,70 lm - pack. 20 Pcs - 54 lm

Article	H mm	
PSLDAA 10	10	

COLOURS

OL - Polished brass	AA - Anodized silver alum.

EXAMPLES OF LAYING

POGRESS L