



PROLEGANT CURVE are a range of edging and joining profiles that may be curved/shaped. They feature a special system of perforations allowing them to be bent easily so that particular geometric shapes may be easily obtained in situ. This allows decorative patterns to be created at will according to technical and aesthetic requirements and with a separation of 6 mm of sandable profile. The product is made in natural brass in 2.7 m bars and heights of 8-10-12.5 and 14 mm.

PROLEGANT CURVE

NATURAL BRASS CURVABLE



NATURAL BRASS CURVABLE thermo packed 5 Pcs
bar length 2,7 lm - pack. 20 Pcs - 54 lm

Article	H mm		
PELONCV 08	8		
PELONCV 10	10		
PELONCV 125	12,5		
PELONCV 14	14		

COLOURS



PELONCV 08



PELONCV 10




PELONCV 125



PELONCV 14



EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS




1. Choose the "PROLEGANT CURVE" in the required height and material. 2. Cut the profile to the necessary length, calculating the total length. 3. Bend the profile mechanically with the PROCURVE MACHINE. 4. If necessary fix with screws and screw anchors or simply insert the punched base under the floor laid with the same adhesive. Any oxidation marks may be easily removed with specific chemical products (Sidel-Smac, etc.).

PROLEGANT CURVE are a range of edging and joining profiles that may be curved/shaped. They feature a special system of perforations allowing them to be bent easily so that particular geometric shapes may be easily obtained in situ. This allows decorative patterns to be created at will according to technical and aesthetic requirements and with a separation of 6 mm of sandable profile. The product is made in silver anodized aluminium in 2.7 m bars and heights of 8-10-12.5 mm.

PROLEGANT CURVE


ANODIZED SILVER ALUMINIUM CURVABLE



ANODIZED SILVER ALUMINIUM CURVABLE thermo packed
bar length 2,7 lm - pack. 20 Pcs - 54 lm

Article	H mm		
PELAACV 08	8		
PELAACV 10	10		
PELAACV 125	12,5		

COLOURS



PELAACV 08




PELAACV 10



PELAACV 125



EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS



1. Choose the "PROLEGANT CURVE" in the required height and material. 2. Cut the profile to the necessary length, calculating the total length. 3. Bend the profile mechanically with the PROCURVE MACHINE. 4. If necessary fix with screws and screw anchors or simply insert the punched base under the floor laid with the same adhesive. Any oxidation marks may be easily removed with specific chemical products (Sidel-Smac, etc.).

* = Production on demand with minimum quantity of 100 pcs. Production delay 4/5 weeks. Price to be agreed